

THE BOUTEZ EN AVANT

SAN FRANCISCO PELICAN CLASS SAILING DORY- PRAM

KEY

1. Side planking sheer tabs - adhere to underside of deck.
2. Bow tab - adhere to underside of deck.
3. Bow tab, starboard side - adhere to starboard planking.
4. Stern tab - adhere to bottom planking.
5. Side planking chine tabs - adhere to bottom planking.
6. Bow tab - adhere to bottom planking.
7. Tiller tabs - adhere to stern.
8. Mast tabs - adhere to deck.
9. Bowsprit tab - adhere to bow.

DECK

NOTE:

CUT ALONG THE SOLID LINES. FOLD ALONG THE DOTTED LINES. ADHERE TABS IN ORDER ACCORDING TO THE KEY. GLUE THE HULL TABS INBOARD. WHITE LIQUID GLUE IS RECOMENDED. HOLD UNTIL SET.

